Installation + User Guide

Plug & Play

Vehicle Kit

Congratulations on the purchase of your new SUPV1C SIRIUS Universal Plug and Play Vehicle Kit

Your new SUPV1C SIRIUS Universal Plug and Play Vehicle Kit lets you enjoy SIRIUS® Satellite Radio's digital entertainment in any vehicle. Use this manual as a guide for the proper installation.

The SUPV1C SIRIUS Universal Plug and Play Vehicle Kit will work with most new SIRIUS plug and play satellite radios. See your Plug and Play user manual for specific product compatibility.

For the latest information about this and other SIRIUS products and accessories, visit http://www.siriuscanada.ca.

SIRIUS®
SATELLITE RADIO

Table of Contents

TABLE OF CONTENTS **3**

WARNING AND SAFETY INFORMATION **4**

IC Caution 4

Safety Precautions 4

Product Compatibility Notice 5

Warnings 6

COPYRIGHTS & TRADEMARKS **7**

PACKAGE CONTENTS **8**

CONTROLS **10**

INSTALLATION **11**

Installing the Vehicle Dock 11

Installing the Antenna 17

Antenna Mounting 17

Cable Routing 20

Connecting the Cigarette Lighter Adapter 28

Docking the SIRIUS Radio 28

Maximizing Audio Quality From Your SIRIUS Radio 30

Wireless Connection 30

Direct Connections 32

Subscribing to the SIRIUS Service 34

TROUBLESHOOTING **35**

OPTIONAL ACCESSORIES **36**

WARRANTY **37**

SPECIFICATIONS **39**

SIRIUS ID **40**

Warning and Safety Information

IC Caution

“Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.”

“To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (EIRP) is not more than that required for successful communication”.

“This device has been designed to operate with an antenna having a maximum gain of [2] dBi. Antenna having a higher gain is strictly prohibited per regulations of Industry Canada. The required antenna impedance is 50 ohms.”

“To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that permitted for successful communication.”

This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Safety Precautions

Be sure to observe the following warnings. Failure to follow these safety instructions and warnings may result in a serious accident and/or personal injury.

- Installation must be performed according to this installation guide. SIRIUS is not responsible for issues arising from installations not performed according to the procedures in this guide.

- Do not operate the SIRIUS radio in a way that might divert your attention from driving safely. As a driver, you alone are responsible for safely operating your vehicle in accordance with traffic safety laws at all times.
- Do not install the unit where it may obstruct your view through the windshield, or of your vehicle's indicator displays.
- Before attaching the suction cup mount to your windshield, you should check your state and local laws for regulations regarding mounting this device on your windshield.
- Do not install the unit where it may hinder the function of safety devices such as an airbag. Doing so may prevent the airbag from functioning properly in the event of an accident.
- To avoid short circuits, do not open the unit, and never put or leave any metallic objects (coins, tools, etc.) inside the vehicle dock.
- If the unit emits smoke or unusual odors, turn the power off immediately, and disconnect the unit from any power source.
- Do not drop the unit or subject it to strong shocks.
- The installation and use suggestions contained in this manual are subject to any restrictions or limitations that may be imposed by applicable law. The purchaser should check applicable law for any restrictions or limitations before installing and/or operating this unit.

Product Compatibility Notice

The SUPV1C is compatible only with plug and play products that use the New SIRIUS Universal Docking capability. This product specifically is not intended nor is it approved for use with SIRIUS radios exhibiting FCC identification numbers NKRUPASV301, NKRUPAST401, P3HSP4, P3HNSPH4, P3HNSPH3, or P3HNSPH-3.

Warnings

Operating Temperature

The SIRIUS Cigarette Lighter Adapter is designed to operate between -20° to +85° C (-4° to +185° F). Avoid leaving it in a vehicle or elsewhere where the temperature may fall outside this range.

Cleaning and Maintenance

If the vehicle dock becomes dirty, turn the power off and wipe it clean with a soft cloth. Do not use hard cloths, strong cleaning fluids, paint thinner, alcohol, or other volatile solvents to clean. These may cause damage to the unit.

Cigarette Lighter Adapter

The SUPV1C cannot be powered directly from a vehicle's 12 VDC power system. It must be powered using the included Cigarette Lighter Adapter only. Connecting the SUPV1C directly to the vehicle's 12 VDC power system may result in damage to the vehicle dock or SIRIUS radio, or both.

Copyrights & Trademarks

© 2007 SIRIUS Satellite Radio Inc. All Rights Reserved.

® “SIRIUS”, the SIRIUS dog logo, channel names and logos are trademarks of Sirius Satellite Radio Inc. All Rights Reserved.

Hardware, subscription, and activation fee required. For full Terms & Conditions, visit http://siriuscanada.ca. Prices and programming are subject to change. Not available in HI and AK. Equipment and subscription sold separately. Installation required with some equipment.

Package Contents

The following items are included with your purchase of the SUPV1C SIRIUS Universal Plug and Play Vehicle Kit. Unpack the kit carefully and make sure that everything shown is present. If anything is missing or damaged, or if the kit fails to operate properly, notify your dealer immediately. It is recommended that you retain the original carton and packing materials in case you need to ship your kit in the future.



Vehicle Dock



Vehicle Dock Adapter



Suction Cup Mount



Vent Mount & Extended Vent Hooks



Cigarette Lighter Adapter



Magnetic Antenna



Antenna Cover/Tail



Mounting Screws



Alcohol Swab

Controls

Figure 1 and the section following identify and describe the controls and connectors of the vehicle dock.



Figure 1

1. **Lock Switch**: Locks and unlocks the SIRIUS radio in the vehicle dock.
2. **Mounting Holes**: Mounting holes for attaching the suction cup mount or the vent mount.
3. **FM OUT Connector**: FM output for use with the optional FM Direct Adapter.
4. **AUDIO OUT Connector**: Optional audio output connection for connecting to your vehicle's audio system if you are not using the FM transmitter.
5. **DC5V Power Connector**: Power connection for the cigarette lighter adapter.
6. **ANT Antenna Connector**: Connection for the provided magnetic antenna.

Installation

SIRIUS suggests professional installation of this product in your vehicle. Professional installation provides an experienced technician to install this product in your vehicle, advice for selecting a suitable mounting location, installation of the antenna, and routing all the necessary wires and cables. If the FM reception within your vehicle proves to be poor, an installer will have the necessary accessories to install an optional FM Direct Adapter, or an audio cable, to connect the audio output of the vehicle dock directly to your vehicle's audio system. Ask your SIRIUS retailer if they provide professional installation services, or can recommend a professional installation service.

Installing the Vehicle Dock

When installing the vehicle dock in your vehicle, choose a location in your vehicle where it will not block your vision, interfere with the vehicle controls, or obstruct the air bag. The location should be easily accessible and provide good visibility of the display, and should not be located where it will be in direct sunlight which will affect the visibility of the display screen.

The mounting accessories necessary to install the vehicle dock in a vehicle are provided. Figure 2 shows two examples of the SIRIUS radio mounted in a vehicle: **A** is the suction cup mount method, and **B** is the vent mount method using the vent mount clip.



Figure 2

Depending upon the mounting location you select in your vehicle, the mount should be attached to the vehicle dock and installed as described in the following sections.

Suction Cup Mount Method (A)

The suction cup mount may be attached to any smooth surface.

To mount the vehicle dock using the suction cup mount, assemble the mount as follows:

1. Attach the vehicle dock to the suction cup mount using the provided screws. (Figure 3)



Figure 3

2. Clean the area where you are attaching the suction cup with an alcohol wipe.

3. Be sure the cam lever is up (as shown in Figure 4) and position the suction cup mount on the windshield or other location you which have chosen. Press the cam lever all the way down towards the base of the mount until it locks to adhere the suction cup. (To unlock the suction cup, lift the lever up.)



Figure 4

Vent Mount Method (B)

To mount the vehicle dock using the vent mount method, install the vent mount as follows:

1. If the vent louvers in your vehicle are recessed, you may need to use the longer vent hooks with the vent mount. Refer to Figure 5 and install the longer vent hooks into the vent mount. Be sure to observe the orientation of the vent hooks as shown.



Figure 5

2. Attach the vent mount to the vehicle dock using the provided screws. (Figure 6)



Figure 6

3. Refer to Figure 7 and attach the vent mount to a heating/air conditioning vent in your vehicle. Position the two tension springs **A** against a vent louver **B**. Then push the vent mount into the vent, far enough so that the hooks **C** drop down and hook the rear of the vent louver (Figure 8). Once you are sure that the hooks have grasped a vent louver, the tension springs **A** will keep the vent mount hooked to the louver.



Figure 7



Figure 8

4. The angle of the vehicle dock may be changed by changing the position of foot **D** on the vent mount (Figure 6) to a different adjustment hole. (Figure 9)



Figure 9

Installing the Antenna

The installation of the magnetic antenna consists of two installation steps:

- Mounting the magnetic antenna and cover/tail on the vehicle
- Routing the antenna cable through the vehicle to the SIRIUS radio or vehicle dock

The following sections provide instructions for both installation steps.

ANTENNA MOUNTING

The SIRIUS Magnetic Mount Vehicle Antenna has a strong magnetic mount designed to hold the antenna in place during normal driving conditions (highway/city). This also allows for easy removal for transferring the antenna to other vehicles.

Figure 10 shows the optimal mounting location for the antenna on several types of vehicles. These mounting positions should be observed when installing the antenna:

- **Sedan/Coupe/SUV/Mini-Van:** Install the antenna at the rear center of the roof, near the rear window.
- **Pickup Truck:** Install the antenna at the front center of the roof, near the windshield.
- **Convertible:** Install the antenna at the front center of the trunk lid, near the rear window.

The SIRIUS antenna needs to have an **unobstructed area of 3 inches by 3 inches around it**. It is important to mount the antenna where no obstructions will block the antenna from receiving the SIRIUS signal. Objects which can obstruct the antenna could be a roof rack, a sunroof, a roof mounted cargo container, another antenna, etc. If your vehicle has a potential obstruction, be sure that the SIRIUS antenna is mounted at least 3 inches away from it (but no closer than 3 inches from the roof edge, or trunk lid in the case of a convertible).



Sedan/Coupe



Pickup Truck



SUV/Mini-Van



Convertible

Figure 10

Follow this procedure to mount the antenna:

1. Select an appropriate mounting position for your type of vehicle that has an unobstructed area of 3 inches by 3 inches around the antenna.
2. Attach the rubber cover/tail to the antenna, as shown in Figure 11, and press the antenna cable into the rubber cover/tail. The rubber cover/tail will help to position the antenna the correct distance from the edge of the roof or trunk lid.
3. Clean the surface area of the vehicle where you will be installing the antenna with the alcohol prep pad.
4. Peel the protective material from the adhesive strips (Figure 11) and press the rubber cover/tail firmly into place on the vehicle (Figure 12).



Figure 11

5. Double check that the location of the antenna and rubber cover/tail are correct, and continue to press firmly down on rubber cover/tail for another 30 seconds. At room temperature (68 degrees), maximum adhesion usually occurs within 72 hours. During this period, avoid car washes and other contact with the antenna and rubber antenna cable cover/tail.



Figure 12

CABLE ROUTING

When you have successfully mounted the antenna, you can begin the cable routing portion of the installation. Separate antenna cable routing procedures are provided for each type of vehicle:

- **Sedan/Coupe** on page 21
- **Pickup Truck** on page 23
- **SUV/Mini-Van** on page 25
- **Convertible** on page 27

Note that additional breakout illustrations for each step of the antenna cable routing procedures can be found on the SIRIUS website at http://www.siriuscanada.ca. Click on the **Install/Activate** link and then follow the link for the **Car Installation Tips**.

Sedan/Coupe Antenna Cable Routing Procedure

Figure 13 shows how the antenna cable should be routed from the antenna to your SIRIUS radio in a sedan/coupe.


1. Feed Cable Under Rubber Molding Around Window
2. Route Cable Out of Window Molding and Into Weatherstripping Around Trunk Opening
3. Route Cable Along Trunk Wall and Into Cabin
4. Route Cable from Trunk Under Interior Trim, into Cabin and Towards Front of Vehicle
5. Bring Cable out from Trim and Route Under Carpet to Dashboard or Console.
6. Bring Cable Out To SIRIUS Radio Location

Figure 13

Follow these detailed cable installation instructions:

1. Feed the cable from the antenna underneath the rubber molding around the rear window. Use a plastic putty knife or similar object to lift the rubber molding around the rear window and tuck the antenna cable underneath the molding. Route the antenna cable around and down the window to the lowest point. If your rear window does not have rubber molding, SIRIUS recommends consulting with a professional installer.
2. Route the antenna cable out of the window molding and into the rubber weather stripping around the trunk opening. Lift the weather stripping from the opening and tuck the cable inside it, then replace the weather stripping. To avoid sharp

bends in the cable, run the cable inside of the weather stripping for a few inches, then remove the cable from the weather stripping inside of the trunk. Keep the cable away from hinges, gears, etc., that could damage it.

3. Route the cable out from the rubber weather stripping and along the trunk wall. Continue routing the cable into the cabin through a conduit or along an existing wiring harness.
4. Route the cable through the main cabin area under the interior trim, towards the front of the vehicle. Use the plastic putty knife to lift the plastic trim just enough to tuck the cable under underneath. Avoid side airbag locations on back pillars and above the doors. (Airbag locations are marked with “SRS” logos.) Be careful not to crimp or cut the cable.
5. Bring the cable out from the trim near the firewall and route it under the carpet toward the dashboard or console. Coil any excess cable in a hidden location, such as under the carpet, keeping it away from any vehicle pedals or controls. Secure the excess cable with wire ties.
6. Bring the end of the cable out at the SIRIUS radio location. Leave yourself enough cable so you can easily connect it to the antenna connector of the SIRIUS radio or vehicle dock.

Pickup Truck Antenna Cable Routing Procedure

Figure 14 shows how the antenna cable should be routed from the antenna to your SIRIUS radio in a pickup truck.


1. Route Cable Under Rubber Molding Around Windshield
2. Continue Tucking Cable Under Molding To Bottom of Windshield
3. Route Cable Out of Molding and Into Weatherstripping Around Door Opening. Continue to Bottom of Door Opening.
4. Bring Cable out from Weatherstripping and Route Under Carpet.
5. Bring Cable Out to SIRIUS Radio Location

Figure 14

Follow these detailed cable installation instructions:

1. Use a plastic putty knife or similar tool to lift the rubber molding around the windshield and tuck the antenna cable underneath it.
2. Continue tucking the cable underneath the windshield molding around the windshield to the lowest corner.
3. At the lowest corner of the windshield, route the cable out of the windshield molding and into the rubber weather stripping around the door opening. Lift the

weather stripping from the opening and tuck the cable inside it, then replace the weather stripping. Run the cable inside of the weather stripping to the bottom of the door opening.

4. Pull the cable out of the weather stripping at the bottom of the door opening and route it under the carpet toward the dashboard. Coil any excess cable in a hidden location, such as under the carpet, keeping it away from any vehicle pedals or controls. Secure the excess cable with wire ties.
5. Bring the end of the cable out at the SIRIUS radio location. Leave yourself enough cable so you can easily connect it to the antenna connector of the SIRIUS radio or vehicle dock.

SUV/Mini-Van Antenna Cable Routing Procedure

Figure 15 shows how the antenna cable should be routed from the antenna to your SIRIUS radio in an SUV or a Mini-Van.


1. Feed Cable Under Rubber Seal Around Hatch Opening
4. Bring Cable Out To SIRIUS Radio Location
3. Route Cable Under Carpet to Dashboard
2. Route Cable Under Interior Trim, into Cabin and Towards Front of Vehicle

Figure 15

Follow these detailed cable installation instructions:

1. Feed the antenna cable underneath the rubber weather stripping of the rear tailgate window/door and route the cable along the rear hatch. Lift the weather stripping from the opening and tuck the cable inside it, then replace the weather stripping. Pull the cable out from weather stripping and route it into the cabin under the interior trim. Avoid hinges or gears that could crimp or cut the cable.
2. Route the cable through the SUV's main cabin area under the interior trim, towards the front of the vehicle. Use a plastic putty knife to lift the plastic trim just enough to tuck the cable under underneath. Avoid side airbag locations on back

pillars and above the doors. (Airbag locations are marked with “SRS” logos.) Be careful not to crimp or cut the cable.

3. Bring the cable out from the trim near the firewall and route it under the carpet toward the dashboard or console. Coil any excess cable in a hidden location, such as under the carpet, keeping it away from any vehicle pedals or controls. Secure the excess cable with wire ties.
4. Bring the end of the cable out at the SIRIUS radio location. Leave yourself enough cable so you can easily connect it to the antenna connector of the SIRIUS radio or vehicle cradle/dock.

Convertible Antenna Cable Routing Procedure

Figure 16 shows how the antenna cable should be routed from the antenna to your SIRIUS radio in a convertible.


6. Bring Cable Out To Docking Station Location and Connect to the Docking Station
1. Bring Cable from Antenna Into Inside of Trunk Lid
5. Bring Cable out from Trim and Route Under Carpet to Dashboard or Console.
4. Route Cable from Trunk Under Interior Trim, into Cabin and Towards Front of Vehicle
2. Tape Cable Along Inside of Lid to Hinge Strut
3. Tie Cable to Hinge Strut, Allowing Slack for Lid to Open and Close. Route Cable Into Cabin Through Existing Wire Channel.

Figure 16

Follow these detailed cable installation instructions:

1. Bring the cable from the antenna into the trunk at the front edge of the trunk lid. Keep any bends in the cable loose. Tape or tie the cable along the inside of the trunk lid to the trunk lid hinge strut.
2. Allow enough slack in the cable so the trunk lid can easily open and close and keep the cable away from hinges, gears, etc., that could crimp or cut it. Route the cable along the trunk wall and into the cabin through a conduit or along an

existing wiring harness.

3. Route the cable through the main cabin area under the interior trim, towards the front of the vehicle. Use a plastic putty knife to lift the plastic trim just enough to tuck the cable under underneath. Avoid side airbag locations on back pillars and above the doors. (Airbag locations are marked with “SRS” logos.) Be careful not to crimp or cut the cable.
4. Bring the cable out from the trim near the firewall and route it under the carpet toward the dashboard or console. Coil any excess cable in a hidden location, such as under the carpet, keeping it away from any vehicle pedals or controls. Secure the excess cable with wire ties.
5. Bring the end of the cable out at the SIRIUS radio location. Leave yourself enough cable so you can easily connect it to the antenna connector of the SIRIUS radio or vehicle dock.

Connecting the Cigarette Lighter Adapter

Connect the provided cigarette lighter adapter to the **DC5V** connection at the rear of the vehicle dock. (Refer to Figure 1 on page 10 for the location of this connector.)

Docking the SIRIUS Radio

If your radio is a SIRIUS Plug and Play series ST or SV, you will need to install the vehicle dock adapter provided with the kit. Refer to Figure 17 and place the vehicle dock lock in the unlocked position (1). Install the adapter into the front of the vehicle dock, positioning it behind the connector and against the backrest (2). Once the adapter is installed in the vehicle dock, slide the lock to the locked position (3). The radio may now be placed into the vehicle dock, pressing the radio down until it is fully seated.



Figure 17

For SIRIUS radios which do not require the adapter, make sure the lock on the vehicle dock is set in the unlocked position and place the SIRIUS radio into the vehicle dock, pressing the radio down until it is fully seated. Slide the lock into the locked position. (Refer to Figure 1 on page 10 for the location of the lock.)

Maximizing Audio Quality From Your SIRIUS Radio

There are two primary ways to connect your SIRIUS radio to your vehicle radio: **Wireless Connection** or **Direct Connection**. The following sections will help you obtain the best performance. For the latest information go to **http://www.siriuscanada.ca/en/install/vehicle.aspx**.

WIRELESS CONNECTION

Your SIRIUS radio contains an FM transmitter. The FM transmitter sends the audio from your SIRIUS radio to your vehicle radio. (Figure 18)



Figure 18

Should the wireless audio quality not be acceptable, you can try using a direct connection).

Wireless Audio Connection

To tune your vehicle's FM radio and your SIRIUS radio to the same FM channel:

1. Turn off your SIRIUS radio and tune through the FM channels on your vehicle's radio to locate an FM channel that is not broadcasting in your area. If you use an FM channel that is being used by a local broadcaster, it will interfere with the performance of your SIRIUS radio. Once you have located an FM channel that is not broadcasting in your area, save it as a preset on your vehicle radio. This will become your SIRIUS preset.
2. Turn on your SIRIUS radio. In the *Settings* or *Menu* in your SIRIUS radio, locate the ***FM Frequency*** adjustments. Set the channel number on your SIRIUS radio to match the SIRIUS preset on your vehicle's radio. Refer to your user guide for detailed instructions on how to do this.

   Note: The FM transmitter in your SIRIUS radio is automatically set to FM channel 88.1. This may not be the best channel in your area.

   Tip: If you regularly travel between cities with different active FM channels, you may need to find channels that are not broadcasting in each city. Several SIRIUS radio models can store multiple FM transmit channels, so you can easily switch to the best FM channel for each city. Refer to your user guide for details on this feature. You will also want to set the FM channels that are not broadcasting in each city as presets on your vehicle's radio.

If you're not sure which FM channels are not broadcasting in your home or travel cities, you can also go to **http://www.siriuscanada.ca/en/install/frequency.aspx** and search for a suggested FM channel based on your zip code.

You should now hear the audio from your SIRIUS radio over your vehicle's FM radio.

DIRECT CONNECTIONS

A direct connection provides better audio performance than a wireless connection and removes the possibility of interference from local FM broadcasters. There are several ways to directly connect your SIRIUS radio which are explained in the following sections.

Tip: Depending on the model of radio in your vehicle and your level of comfort with in-car installations, a direct connection may require professional installation assistance. Ask your retailer or contact SIRIUS customer support for recommended installers in your area.

Direct Wired Audio Connection

If your vehicle radio offers an “AUX IN” or “LINE IN” connection, it is the best audio connection available. If the “AUX IN” or “LINE IN” connector is located on the front of your vehicle radio, this is also the easiest connection. (Figure 19)

1. Purchase an audio cable that matches the connection type of your vehicle radio and your SIRIUS radio at your local electronics retailer. Your SIRIUS radio requires a 1/8” stereo male connector. Your local electronics retailer can help you determine the proper connection for your vehicle radio.
2. Plug one end of the cable into the **LINE OUT** jack on the vehicle dock. (Refer to Figure 1 on page 10.) Plug the other end into your “AUX IN” or “LINE IN” jack on your vehicle radio.



Figure 19

Note: Refer to your vehicle radio manufacturer’s guidelines for correct installation.

Note: If the “AUX IN” or “LINE IN” connection is on the back of your vehicle radio, you may want to consider professional installation. (Figure 20)



Figure 20

Cassette Adapter

If your vehicle radio has a cassette player:

1. Purchase a Cassette Adapter at your local electronics retailer.
2. Connect the adapter between the **LINE OUT** on the vehicle dock (refer to Figure 1 on page 10), and the vehicle radio's cassette slot. (Figure 21)

Note: Refer to the cassette adapter manufacturer's guidelines for correct use.



Figure 21

Subscribing to the SIRIUS Service

Before you can listen to the SIRIUS service, you need to subscribe to the SIRIUS Satellite Radio service. To subscribe, do the following:

1. Be sure that the SIRIUS radio is correctly installed, is in the vehicle or home dock, and that the antenna is oriented to receive the SIRIUS signal.
2. Turn on the radio. After the startup sequence, it will update the SIRIUS channel line-up. Wait until the channel updates have completed before pressing any buttons.
3. Once the channels have been updated, the display will change to *Call 1-888-539-SIRIUS to Subscribe* and will tune to channel 184. You will not be able to listen to other channels until you activate your SIRIUS subscription.
4. Use the radio's channel up/down buttons to tune to channel **0** to display the radio's unique 12-digit SIRIUS ID Number (SID). (Figure 1) You can also tune to channel **0** by using the remote control: Press the **Select** button then the **0** (zero) button and then press the **Select** button again. The SID number is also available on the radio's packaging, and may also be accessed by pressing the **MENU** button and selecting *Sirius ID*. Write the SID number down in the space provided near the end of this guide.
5. Have your credit card handy and contact SIRIUS on the Internet at:
   https://activate.siriuscanada.ca/
   and follow the prompts to activate your subscription. You can also call SIRIUS toll-free at: **1-888-539-SIRIUS** (1-888-539-7474).
6. When you have successfully subscribed to the SIRIUS service, and the radio has been updated with your subscription information, an alert will be displayed. To continue, press the **Select** button.

You are now ready to begin enjoying SIRIUS Satellite Radio's digital entertainment, and can tune to other channels!

Troubleshooting

Symptom	Solution
SIRIUS radio does not power on	Blown fuse, or the Cigarette Lighter Adapter is not properly connected. Check the Cigarette Lighter adapter connection. Refer to the vehicle's owners manual for the location of the vehicle's fuse panel and check for a blown fuse.
SIRIUS radio displays: *Antenna Not Detected*	The satellite antenna is not connected to the vehicle dock. Check the satellite antenna connection to the vehicle dock.
SIRIUS radio displays: *Acquiring Signal*	No satellite signal is being received. Check for obstacles over or around the satellite antenna. Change the vehicle location to eliminate nearby obstacles (bridges, overpasses, tress, buildings, etc).
Audio static or loss of clarity	The FM frequency contains static. Locate a quiet FM frequency on your vehicle radio and set the FM transmitter frequency of the SIRIUS radio to match. If using the Audio Out connector, check the cable connections.
No sound	The audio cables are not connected, or the FM radio is set to the wrong frequency. Check the audio cables at the radio and the radio. Verify that the FM transmitter in the radio is set to On. Tune the FM radio to the same FM frequency to which the radio is tuned.

Optional Accessories

The following optional accessories are available for purchase from your SIRIUS retailer to maximize your SIRIUS experience:

SUBX1C SIRIUS Plug and Play Universal Boombox

The SUBX1C SIRIUS Plug and Play Universal Boombox is a portable docking station and audio system for use with the SIRIUS radio. With the built-in amplifier and speakers, the boombox delivers rich, powerful sound indoors or outdoors, and features an auxiliary input for other audio devices.

Included with the boombox is an adjustable indoor/outdoor windowsill antenna with 20' of cable and an AC adapter.

SUPH1C SIRIUS Universal Plug and Play Home Kit

The SUPH1C SIRIUS Universal Plug and Play Home Kit is a compact home dock that positions the radio for easy viewing and operation. Designed for quick and easy self-installation, it includes all necessary cabling to connect your SIRIUS radio to your home audio system.

The kit includes a compact tabletop/desktop home dock with FM output for wireless connectivity, an audio cable for connection to any stereo bookshelf system, an adjustable indoor/outdoor windowsill antenna with 20' of cable, and an AC Adapter.

Warranty

12 Month Warranty

SIRIUS Canada Inc. (the “Company”) warrants to the original retail purchaser of this product that should this product or any part thereof, under normal use and conditions, be proven defective in material or workmanship within 12 months from the date of original purchase, such defect(s) will be replaced with new or reconditioned product (at the Company’s option) without charge for parts and labor. To obtain replacement within the terms of this Warranty, the product is to be delivered with proof of warranty coverage (e.g. dated bill of sale), specification of defect(s), transportation prepaid, to the location shown below under WARRANTY RETURN.

This Warranty does not extend to the elimination of externally generated static or noise, to correction of antenna problems, to costs incurred for installation, removal or reinstallation of the product, or to damage to tapes, compact discs, speakers, accessories, or vehicle electrical systems.

This Warranty does not apply to any product or part thereof which, in the opinion of the Company, has suffered or been damaged through alteration, improper installation, mishandling, misuse, neglect, accident, or by removal or defacement of the factory serial number/bar code label(s). THE EXTENT OF THE COMPANY’S LIABILITY UNDER THIS WARRANTY IS LIMITED TO THE REPAIR OR REPLACEMENT PROVIDED ABOVE AND, IN NO EVENT, SHALL THE COMPANY’S LIABILITY EXCEED THE PURCHASE PRICE PAID BY PURCHASER FOR THE PRODUCT.

This Warranty is in lieu of all other express warranties or liabilities. ANY IMPLIED WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, SHALL BE LIMITED TO THE DURATION OF THIS WRITTEN WARRANTY. ANY ACTION FOR BREACH OF ANY WARRANTY HEREUNDER INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY MUST BE BROUGHT WITHIN A PERIOD OF

48 MONTHS FROM DATE OF ORIGINAL PURCHASE. IN NO CASE SHALL THE COMPANY BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES FOR BREACH OF THIS OR ANY OTHER WARRANTY, EXPRESS OR IMPLIED, WHATSOEVER. No person or representative is authorized to assume for the Company any liability other than expressed herein in connection with the sale of this product. Some states do not allow limitations on how long an implied warranty lasts or the exclusion or limitation of incidental or consequential damage so the above limitations or exclusions may not apply to you. This Warranty gives you specific legal rights and you may also have other rights which vary from state to state.

WARRANTY RETURN: To obtain a replacement within the terms of this Warranty, please return product to an authorized Sirius Canada retailer or call Erikson Consumer Customer Service at (800) 567-3275 for an authorized Sirius retailer near you; proof of purchase and description of defect are required. Products to be returned to an approved warranty station must be shipped freight prepaid.

Specifications

Cigarette Lighter Adapter Fuse Requirement . . . . . 2A Slow Blow
Cigarette Lighter Adapter Cable Length 1.8m (6ft.)
Cigarette Lighter Adapter Operating Temperature . . . . -20° to +85° C (-4° to +185° F)
Vehicle Dock Power Requirements . . . . . .10-16 Volts, Negative Ground, DC
Antenna Type . . . . . .Low Profile Magnetic
Antenna Cable Length . . . . . 21’ (single micro-cable)
Connector Type . . . . . SMB (right-angle)
Audio Out Interface . . . . . 1/8” / 3.5mm Stereo Jack

SIRIUS ID

Write down the SIRIUS ID (SID) of your SIRIUS radio in the space provided below.

SID: _____

SIRIUS
SATELLITE RADIO

www.siriuscanada.ca

SIRIUS Canada Inc.
135 Liberty Street, 4th Floor
Toronto, Ontario M6K 1A7

1.888.539.7474

Plug & Play Vehicle Kit (SUPV1C121207a)
00.ABCD1.001